

CyberKey

Battery Cap Removal Instructions

Step 1

Use a ball-point pen to depress the upper lobe of one of the latches which holds the battery cap in place.



Step 2

Lift the battery cap up, then toward the latch on the opposite side.



Step 3

After replacing the battery, hook one side of the battery cap onto a latch, then snap the opposite end into place over the other latch.

